# Set Up for Enviro+ Sensor with RPi Zero

## marc and kyle

February 14, 2025

## 1 Hardware and Assessories

1. Package list

Raspberry Pi Zero W

Housing

2.5A power supply

Heatsink

Pimonori Enviro+ sensor board

PMS5003 particulate matter sensor

SD Card

## 2 Pi OS and Software

#### 2.1 Tutorials and Resources

https://www.rigacci.org/wiki/doku.php/doc/appunti/hardware/raspberrypi\_air

https://learn.pimoroni.com/article/getting-started-with-enviro-plus

### 2.2 Image SD Card and Upgrade OS

Install Raspberry Pi OS (previously Raspbian) on SD Card

\* Use either a SD card slot or USB/SD card adapter on \*\*\*another\*\*\* computer to connect SD card for OS installation. 1. Download Raspberry Pi Imager for your operating system (OS) at (https://www.raspberrypi.org/downloads/ 2. Install Raspberry Pi Imager 3. Use Raspberry Pi Imager to install/write Raspberry Pi OS to SD card. 1. Customize with the following parameters: \* Choose OS: \*\*Raspberry Pi OS (other)\*\* \* Choose SD Card: \*\*Select the SD card you want to write the OS to\*\* \* Choose Storage: \*\*Choose the size of the SD

card\*\* \* Write: \*\*Click "Write" to write the OS to the SD card\*\* \* Host: Pi#, where # is the number of the Pi you are using.

11. Update Raspberry Pi Zero W. + To make sure the Raspberry Pi Zero W is up to date, run the following commands, one after the other, making sure the process completes each time:

```
sudo apt update
sudo apt full-upgrade
```

This can take 45 minutes with a newly imaged SD card. N

# 3 Python Code Source

## 3.1 Clone Pimoroni Enviro+ Respository

Install Pimoroni Enviro+ software

To install the Pimoroni Enviro+ software, run the following command in the terminal:

```
git clone https://github.come/pimoroni/enviroplus-python
cd enviroplus-python
./install.sh
```

```
Not sure what is going on here...but it takes a while! say no to documentation. creates auto_venv.sh getting lots of python libraries/packagesj library from pypi warning boot/config.txt is not a link to boot/firmware/config.txt FIX how? reboot
```

# 4 Downloading Software

#### 4.1 Following the Pimoroni Tutorial

https://learn.pimoroni.com/article/getting-started-with-enviro-plus

#### 4.2 Cloning the Pimoroni Enviro+ Repository

To install the Pimoroni Enviro+ software, run the following command in the terminal:

```
git clone https://github.come/pimoroni/enviroplus-python
cd enviroplus-python
./install.sh
```

| PiZ ID | OS            | Update  | Repositories | Boot Run |
|--------|---------------|---------|--------------|----------|
|        |               |         | Installed    |          |
| 1      | bookworm (12) | 2/12/25 | EnviroPlus   | No       |
| 2      | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 3      | Not Installed | No      | No           | No       |
| 4      | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 5      | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 6      | bookworm (12) | 2/10/25 | EnviroPlus   | No       |
| 7      | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 8      | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 9      | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 10     | bookworm (12) | Error   | No           | No       |
| 11     | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 12     | bookworm (12) | 2/12/25 | EnviroPlus   | No       |
| 13     | bookworm (12) | 2/13/25 | EnviroPlus   | No       |
| 14     | bookworm (12) | 2/11/25 | EnviroPlus   | No       |
| 15     | bookworm (12) | 2/9/25  | EnviroPlus   | No       |

Table 1: Raspberry Pi Status

install.sh is a shell script that installs the necessary software for the Enviro+board. It will take a few minutes to install all the software. when prompted to create a virtual environment, type "y" and press Enter. After this has been completed, the software will be installed.

After the software has been installed, you will be prompted to install examples. Type "y" and press Enter. When prompted to install the documentation, type "n" and press Enter.

Finally, you should see usk reboot to complete the installation. Type "y" and press Enter to reboot the Raspberry Pi Zero W.

## 4.3 Testing Pimoroni Examples

The Pimoroni board relies on a virtual environment to run the software. To test the Pimoroni Enviro+ software, run the following command in the terminal:

#### source ~/.virtualenvs/pimoroni/bin/activate

Navigate to the examples folder within the enviroplus-python folder:

```
cd enviroplus-python
cd examples
ls
```

There are several examples in the examples folder within the enviropluspython folder. In the terminal, type the following to look at the available examples: The examples folder contains several examples that demonstrate the capabilities of the Enviro+ board.

Weather Sensors This example uses the BME280 sensor to read temperature, pressure, and humidity.

python weather.py

Type "Ctrl + C" to stop the program.

MICS6814 gas sensor example The MICS6814 outputs resistance values in Ohms that correspond to the levels of three different types of gas: reducing, oxidising, and NH3 (more info above). Let's look at the numbers that come out of this sensor by running the gas example now. Type the following in the terminal:

python gas.py

Let it run for a while, and you'll see that the values creep up steadily. The sensor values take quite a while to stabilise, as the sensor warms up gradually. The sensor is sensitive to temperature, so it's important to let it warm up for a few minutes before taking readings.

Type "Ctrl + C" to stop the program.

**Light Sensors** - This example uses the LTR559 light sensor to read ambient light levels.

python light.py

Type "Ctrl + C" to stop the program.

 ${\bf Particulates}\,$  - This example uses the PMS5003 sensor to read particulate matter levels.

python particulates.py

Type "Ctrl + C" to stop the program.<sup>1</sup>

<sup>&</sup>lt;sup>1</sup>Sometimes this "stops" the program, but it continues to run in the background, which blocks the sensor from being used in other programs. If this happens, exit the terminal and restart a new one. I think that will work! But some say you need to reboot the Pi.

## 4.4 Cloning the EJnPi Repository

To clone the EJnPi repository, run the following command in the terminal:

```
git clone https://github.com/marclos/EJnPi
```

The EJnPi repository contains several examples that demonstrate the capabilities of the Enviro+ board, but it's painfully slow!!! Not even that much in there. I don't know why. I read something about the way the repository is set up that the entire history might be included (hidden?). I'll do some research on this at some point.

## 4.5 EJnPi: Pushing and Pulling EJnPi

\*If you have a problem in RStudio with checking commits, it may be a bug. Use RStudio's Terminal and run this command:

```
git commit -v -a
```

Then uncomment one line and enter. This should fix the rest of the unselectable commits.

### 4.6 Testing the EJnPi Repository

To test the EJnPi repository, navigate to the EJnPi folder and run the following command in the terminal:

```
cd EJnPi
ls
```

The EJnPi folder contains several examples that demonstrate the capabilities of the Enviro+ board.

**EA30-bme.py** This program uses the BME280 sensor to read temperature, pressure, and humidity, but writes the data to a CSV file (EA30-bme280\_data.csv) every 60 seconds.

NOTE: I would like to get the data out of this folder... to be continued. Also, each student might have a code for their dataset...

```
python EA30-bme.py
```

Type "Ctrl + C" to stop the program.

**EA30-particulates.py** This program uses the PMS5003 sensor to read particulate matter levels, but writes the data to a CSV file (particulates\_data.csv) every second.

```
python EA30-particulates.py
```

Type "Ctrl + C" to stop the program.

#### 4.7 TESTING SECTION

FYI: Do not use pms5003.py as it interferes with package loading, filename – that will get in the way of the module loading.

#### pms5003\_3.py WORKS

More robust set of variables, saves to csv every 30 seconds. Commented out lines 42, 43, 44.

pms5003\_4.py Added bme280 sensor to the script. WORKS.

I'd like to add gas sensor, but first, need to get the LCD working, so students know it's working when plugged in without needing a HDMI connection.

also the logging info is restricted, not sure what do about that.

pms5003\_5.py ?? LCD?

**Enviroplus\_v0.py** This unmodified from Pironomi, and it works. Every second.

**Enviroplus\_v1.py** This is a modified version get data from all sensors at once. Not started yet.

Enviroplus\_v2.py This is a modified version get data form all sensors and write to a CSV file. Not started yet.

# 5 Set up Script to Run automatically

### 5.1 Setting up a Virtual Environment

https://learn.adafruit.com/python-virtual-environment-usage-on-raspberry-pi/basic-venv-usage

https://learn.adafruit.com/python-virtual-environment-usage-on-raspberry-pi/automatically-running-at-boot

### 5.1.1 Options for Running Script Automatically

If your using the login of pi for example, then the line source /.virtualenvs/pimoroni/bin/activate should be added into the .bashrc file in the /home/pi users folder.

There are several ways to run a script automatically on boot. The easiest way is to use crontab, a job scheduler, which has an @reboot command that will run a script or command when the Pi first boots up.

crontab

systemd

rc.local

An easy way of running a script automatically on boot is to use crontab, a job scheduler, which has an @reboot command that will run a script or command when the Pi first boots up.

In the terminal, type crontab -e and then select nano as the editor.

Scroll down to the very bottom of the file with the arrow keys and type the following line:

@reboot sudo python /home/pi/enviroplus-python/examples/luftdaten.py &

Double- and triple-check this command to make sure that it's exactly correct, as any error will cause it not to run on boot.

Press control-x, then y, then enter to exit and save the new crontab.

You should now shutdown your Raspberry Pi Zero W, either through the Raspberry Pi menu, or by typing sudo shutdown -h now in the terminal.

When running the examples that follow, you can type control-c at any time to stop the example running.

## 6 deployment notes

## 6.1 Shutting doen with GPIO pins

https://learn.adafruit.com/adafruits-raspberry-pi-lesson-13-power-control/shutting-down-the-pi add a button??